


**AKZM 656**



**GB**

**User and maintenance manual**

**PL**

**Instrukcja obsługi i konserwacji**

**RU**

**Руководство по эксплуатации  
и техническому обслуживанию**

**RO**

**Manual de utilizare și întreținere**





# IMPORTANT SAFETY INSTRUCTIONS

## **YOUR SAFETY AND THAT OF OTHERS IS PARAMOUNT**

This manual and the appliance itself provide important safety warnings, to be read and observed at all times.



This is the danger symbol, pertaining to safety, which alerts users to potential risks to themselves and others. All safety warnings are preceded by the danger symbol and the following terms:



### **DANGER**

**Indicates a hazardous situation which, if not avoided, will cause serious injury.**



### **WARNING**

**Indicates a hazardous situation which, if not avoided, could cause serious injury.**

All safety warnings give specific details of the potential risk present and indicate how to reduce risk of injury, damage and electric shock resulting from improper use of the appliance. Carefully observe the following instructions:

- The appliance must be disconnected from the power supply before carrying out any installation work.
- Installation and maintenance must be carried out by a qualified technician, in compliance with the manufacturer's instructions and local safety regulations. Do not repair or replace any part of the appliance unless specifically stated in the user manual.
- Regulations require that the appliance is earthed.
- The power cable must be long enough for connecting the appliance, once fitted in its housing, to the power supply socket.
- For installation to comply with current safety regulations, an all-pole disconnect switch with minimum contact gap of 3 mm must be utilized.
- Do not use multiple plug adapters or extension leads.
- Do not pull the power supply cable in order to unplug the appliance.
- The electrical components must not be accessible to the user after installation.
- Do not touch the appliance with any wet part of the body and do not operate it when barefoot.
- This appliance is designed solely for use as a domestic appliance for cooking food. No other type of use is permitted (e.g.: heating rooms). The Manufacturer declines all responsibility for inappropriate use or incorrect setting of the controls.
- The appliance is not intended for use by persons (including children) with any physical, sensory or mental impairment, or without experience and knowledge of the appliance, unless supervised or previously instructed in its use by those responsible for their safety.
- The accessible parts of the appliance may become very hot during use. Young children should be kept away from the appliance and supervised to ensure that they do not play with it.
- During and after use, do not touch the heating elements or interior surfaces of the appliance - risk of burns. Do not allow the appliance to come into contact with cloths or other flammable materials until all the components have cooled sufficiently.
- At the end of cooking, exercise caution when opening the appliance door, letting the hot air or steam exit gradually before accessing the oven. When the appliance door is shut, hot air is vented from the aperture above the control panel. Do not obstruct the vent apertures.
- Use oven gloves to remove pans and accessories, taking care not to touch the heating elements.
- Do not place flammable materials in or near the appliance: a fire may break out if the appliance is inadvertently switched on.
- Do not heat or cook sealed jars or containers in the appliance. The pressure that builds up inside might cause the jar to explode, damaging the appliance.
- Do not use containers made of synthetic materials.
- Overheated oils and fats catch fire easily. Always remain vigilant when cooking foods rich in fat and oil.
- Never leave the appliance unattended during food drying.
- If alcoholic beverages are used when cooking foods (e.g. rum, cognac, wine), remember that alcohol evaporates at high temperatures. As a result, there is a risk that vapours released by the alcohol may catch fire upon coming into contact with the electrical heating element.

## **Scrapping of household appliances**

- This appliance is manufactured with recyclable or reusable materials. Dispose of it in accordance with local waste disposal regulations. Before scrapping, cut off the power supply cable.
- For further information on the treatment, recovery and recycling of household electrical appliances, contact your competent local authority, the collection service for household waste or the store where you purchased the appliance.

## INSTALLATION

After unpacking the oven, make sure that it has not been damaged during transport and that the oven door closes properly. In the event of problems, contact the dealer or your nearest After-sales Service. To prevent any damage, only remove the oven from its polystyrene foam base at the time of installation.

### **PREPARING THE HOUSING UNIT**

- Kitchen units in contact with the oven must be heat resistant (min 90°C).
- Carry out all cabinet cutting work before fitting the oven in the housing and carefully remove all wood chips and sawdust.
- After installation, the bottom of the oven must no longer be accessible.
- For correct appliance operation, do not obstruct the minimum gap between the worktop and the upper edge of the oven.

### **ELECTRICAL CONNECTION**

Make sure the power voltage specified on the appliance dataplate is the same as the mains voltage. The dataplate is on the front edge of the oven (visible when the door is open).

- Power cable replacement (type H05 RR-F 3 x 1.5 mm<sup>2</sup>) must be carried out by a qualified electrician. Contact an authorized service centre.

### **GENERAL RECOMMENDATIONS**

#### **Before use:**

- Remove cardboard protection pieces, protective film and adhesive labels from accessories.
- Remove the accessories from the oven and heat it at 200° for about an hour to eliminate the smell and fumes from the insulating materials and protective grease.

#### **During use:**


- Do not place heavy objects on the door as they could damage it.
- Do not cling to the door or hang anything from the handle.
- Do not cover the inside of the oven with aluminium foil.
- Never pour water into the inside of a hot oven; this could damage the enamel coating.
- Never drag pots or pans across the bottom of the oven as this could damage the enamel coating.
- Make sure that the electrical cables of other appliances do not touch hot parts of the oven or become trapped in the door.
- Do not expose the oven to atmospheric agents.

## SAFEGUARDING THE ENVIRONMENT

### **Disposal of packing material**

The packing material is 100% recyclable and is marked with the recycle symbol (♻). The various parts of the packing must therefore be disposed of responsibly and in full compliance with local authority regulations governing waste disposal.

### **Scrapping the product**

- This appliance is marked in compliance with European Directive 2002/96/EC, Waste Electrical and Electronic Equipment (WEEE).
- By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.
- The symbol  on the product or on the accompanying documentation indicates that it should not be treated as domestic waste but must be taken to an appropriate collection centre for the recycling of electrical and electronic equipment.

### **Energy saving**

- Only pre-heat the oven if specified in the cooking table or your recipe.
- Use dark lacquered or enamelled baking moulds as they absorb heat far better.
- Switch the oven off 10/15 minutes before the set cooking time. Food requiring prolonged cooking will continue to cook even once the oven is switched off.

## DECLARATION OF CONFORMITY C €

- This oven, which is intended to come into contact with foodstuffs, complies with European Regulation (C €) n.1935/2004 and has been designed, manufactured and sold in conformity with the safety requirements of the "Low Voltage" directive 2006/95/CE (which replaces 73/23/CEE and subsequent amendments), the protection requirements of "EMC" 2004/108/CE.

## TROUBLESHOOTING GUIDE

### **The oven does not work:**

- Check for the presence of mains electrical power and if the oven is connected to the electrical supply.
- Turn off the oven and restart it to see if the fault persists.

### **The electronic programmer does not work:**

- If the display shows the letter “F” followed by a number, contact your nearest After-sales Service. Specify in this case the number that follows the letter “F”.

## AFTER-SALES SERVICE

### **Before calling the After-Sales Service:**

1. See if you can solve the problem yourself with the help of the suggestions given in the “Troubleshooting guide”.
2. Switch the appliance off and back on again it to see if the fault persists.

**If after the above checks the fault still occurs, get in touch with the nearest After-sales Service.**

Always specify:

- a brief description of the fault;
- the type and exact model of the oven;
- the service number (number after the word Service on the rating plate), located on the right hand edge of the oven cavity (visible when the oven door is open). The service number is also indicated on the guarantee booklet;
- your full address;
- your telephone number.

**SERVICE** 0000 000 00000



If any repairs are required, please contact an authorised **After-sales Service** (to guarantee that original spare parts will be used and repairs carried out correctly).

## CLEANING



### **WARNING**

- **Never use steam cleaning equipment.**
- **Only clean the oven when it is cool to the touch.**
- **Disconnect the appliance from the power supply.**

### **Oven exterior**

**IMPORTANT: do not use corrosive or abrasive detergents. If any of these products accidentally comes into contact with the appliance, clean immediately with a damp cloth.**

- Clean the surfaces with a damp cloth. If it is very dirty, add a few drops of washing up detergent to the water. Finish off with a dry cloth.

### **Oven interior**

**IMPORTANT: do not use abrasive sponges or metallic scrapers or scourers. Over time, these can ruin enamelled surfaces and the oven door glass.**

- After every use, allow the oven to cool then clean it preferably while it is still warm in order to remove built-up dirt and stains caused by food residues (e.g. food with a high sugar content).
- Use proprietary oven detergents and follow the manufacturer's instructions to the letter.
- Clean the door glass with a suitable liquid detergent. The oven door can be removed to facilitate cleaning (see MAINTENANCE).
- The top heating element of the grill (see MAINTENANCE) can be lowered (some models only) to clean the roof of the oven.

**N.B.: during prolonged cooking of foods with a high water content (e.g. pizza, vegetables, etc.) condensation may form on the inside of the door and around the seal. When the oven is cold, dry the inside of the door with a cloth or sponge.**

### **Accessories:**

- Soak the accessories in water with washing up detergent immediately after use, handling them with oven gloves if still hot.
- Food residues can be easily removed using a brush or sponge.

### **Cleaning the rear wall and catalytic side panels of the oven (if present):**

**IMPORTANT: do not use corrosive or abrasive detergents, coarse brushes, pot scourers or oven sprays which could damage the catalytic surface and ruin its self-cleaning properties.**

- Operate the oven empty with the fan-assisted function at 200°C for about one hour
- Next, leave the appliance to cool down before removing any food residue with a sponge.

## MAINTENANCE

### WARNING

- Use safety gloves.
- Ensure the oven is cold before carrying out the following operations.
- Disconnect the oven from the power supply.

## REMOVING THE DOOR

### To remove the door:

1. Open the door fully.
2. Lift the catches and push them forwards as far as they will go (fig. 1).
3. Close the door as far as it will go (A), lift it up (B) and turn it (C) until it is released (D) (fig. 2).

### To refit the door:

1. Insert the hinges in their seats.
2. Open the door fully.
3. Lower the two catches.
4. Close the door.




Fig. 1




Fig. 2

## MOVING THE TOP HEATING ELEMENT (SOME MODELS ONLY)

1. Remove the side accessory holder grilles (Fig. 3).
2. Pull the heating element out a little (Fig. 4) and lower it (Fig. 5).
3. To reposition the heating element, lift it up, pulling it slightly towards you, making sure it comes to rest on the lateral supports.




Fig. 3




Fig. 4




Fig. 5

## REPLACING THE OVEN LAMP

**To replace the rear lamp** (if present):

1. Disconnect the oven from the power supply.
2. Unscrew the lamp cover (Fig. 6), replace the lamp (see note for lamp type) and screw the lamp cover back on.
3. Reconnect the oven to the power supply.

**To replace the side lamp** (if present):

1. Disconnect the oven from the power supply.
2. Remove the side accessory holder grilles, if present (Fig. 3).
3. Use a screwdriver to prise off the lamp cover (Fig. 7).
4. Replace the lamp (see note for lamp type) (Fig. 8).
5. Reposition the lamp cover, pushing it on firmly until it snaps into place (Fig. 9).
6. Refit the side accessory holder grilles.
7. Reconnect the oven to the power supply.




Fig. 6




Fig. 7




Fig. 8




Fig. 9

**N.B.:**


- Only use 25-40W/230V type E-14, T300°C incandescent lamps, or 20-40W/230 V type G9, T300°C halogen lamps.
- Lamps are available from our After-sales Service.

**IMPORTANT:**

- **If using halogen lamps, do not handle with bare hands since fingerprints can damage them.**
- **Do not use the oven until the lamp cover has been repositioned.**

# INSTRUCTIONS FOR OVEN USE

FOR ELECTRICAL CONNECTION, SEE THE PARAGRAPH ON INSTALLATION



1. Control panel
2. Upper heating element/grill
3. Cooling fan (not visible)
4. Dataplate (not to be removed)
5. Lamps
6. Circular heating element (not visible)
7. Fan
8. Turnspit (if present)
9. Lower heating element (not visible)
10. Door
11. Position of shelves (the number of shelves is indicated on the front of the oven)
12. Rear wall

## N.B:

- During cooking, the cooling fan may switch on at intervals in order to minimise energy consumption.
- At the end of cooking, after the oven has been switched off, the cooling fan may continue to run for a while.
- When the oven door is opened during cooking, the heating elements switch off.

## ACCESSORIES SUPPLIED




Fig. A




Fig. B




Fig. C




Fig. D




Fig. E

- A. WIRE SHELF (n. 1):** the wire shelf can be used to grill food or as a support for pans, cake tins and other ovenproof cooking receptacles.
- B. DRIP TRAY (n. 1):** the drip tray is designed to be positioned under the wire shelf in order to collect fat or as an oven tray for cooking meat, fish, vegetables, focaccia, etc.
- C. BAKING TRAY (n. 2):** for cooking all bread and pastry products, but also roasts, fish en papillote, etc.
- D. CATALYTIC PANELS (n. 2):** for easier and more thorough cleaning of the oven walls.
- E. SLIDING RUNNERS:** to facilitate insertion and removal of accessories.

## ACCESSORIES NOT SUPPLIED

Other accessories can be purchased separately from the After-sales Service.



## **INSERTING WIRE SHELVES AND OTHER ACCESSORIES IN THE OVEN**

The wire shelf and other accessories are provided with a locking mechanism to prevent their accidental removal.




Fig. 1

1. Insert the wire shelf horizontally, with the raised part "A" upwards (fig. 1).
2. Angle the wire shelf when it reaches the locking position "B" (fig. 2).




Fig. 2




Fig. 3

3. Return the wire shelf to the horizontal position and push it in fully to "C" (fig. 3).
4. To remove the wire shelf proceed in reverse order.

The other accessories, like the drip tray and baking tray, are inserted in exactly the same way. The protrusion on the flat surface enables the accessories to lock in place.

## **CONTROL PANEL DESCRIPTION**




**TOUCH KEYS:** to use, simply touch the corresponding symbol (a light touch is all that is required).

- ⓘ On/Off
- MENU to access the main MENU or return to the start screen
- ☆ to access the 10 most used functions
- ⏪ to return to the previous screen
- ⬆ ⬇ to browse the functions/options and change pre-set values
- ✓ to select and confirm settings
- ▶ to start cooking

## LIST OF FUNCTIONS

After switching on the oven, press the symbol ① and the display will show the following indications.



- A. Symbol for highlighted function
- B. Highlighted function can be selected by pressing
- C. Description of highlighted function
- D. Further available, selectable information

## DETAILS OF FUNCTION

After selecting the desired function, press button and the display will show further options and related details



To move between different areas, use buttons and : the cursor moves to the adjustable values, following the order described above. Press to select the value, adjust it using and confirm by pressing button .

## USING THE APPLIANCE FOR THE FIRST TIME - LANGUAGE SELECTION AND SETTING THE TIME

For correct use of the oven, when it is switched on for the first time you will have to select the desired language and set the correct time.

Proceed as follows:


1. Press ①: the display will show the list of the first three available languages.
2. Press buttons and to scroll down the list.
3. When the desired language is highlighted, press to select it.  
**After language selection, the display will flash 12:00.**
4. Set the time using buttons and . To scroll through the numbers more quickly, keep the button pressed.
5. Confirm your setting by pressing : the display will show the list of functions.

## SELECTING COOKING FUNCTIONS



1. If the oven off press button ①; the display will show the cooking functions.
2. To browse the various possibilities, press buttons : the selectable function is highlighted in white in the centre of the screen.  
**N.B: for the list and description of functions, see the specific table at page 12 and at page 13.**
3. Select the function by pressing button : the cooking settings are displayed on the screen. If the pre-set values are those desired, press the start button , otherwise proceed as indicated above to change them.


## SETTING THE TEMPERATURE/OUTPUT OF THE GRILL



To change the temperature or output of the grill, proceed as follows:

1. Check that the cursor is positioned next to the temperature value (zone 1); press button to select the parameter to be changed: the temperature values flash.
2. Use buttons to change to the desired value.
3. Press button to confirm and then press . The display indicates which shelf food should be placed on.
4. Press to start cooking.  
**The set temperature can also be changed during cooking by following the same procedure.**
5. At the end of cooking, the end of cooking message is displayed. At this point the oven can be switched off by pressing , or cooking can be prolonged by pressing . When switched off, the display shows the cooling bar which indicates the temperature inside the oven.


## PREHEATING THE OVEN



If you wish to preheat the oven before inserting food, change the oven's default selection as follows:

1. Using buttons and , move the cursor to preheating.
2. Press button to select the setting: "No" flashes on the display.
3. To change the setting, press or : the display shows "Yes".
4. To confirm your choice, press button .


## FAST PREHEATING



If you wish to preheat the oven quickly before inserting food, change the oven's default selection as follows:

1. Select the fast preheating function using buttons .
2. Confirm by pressing : the settings are displayed on the screen.
3. If the proposed temperature is that desired, press , otherwise proceed as described in previous paragraphs to change it. An acoustic signal will sound when the oven has reached the set temperature. At the end of preheating, the oven automatically selects the conventional function .
- At this point food can be placed in the oven for cooking.**
4. If you wish to set a different cooking function, press and select the desired function.

## SETTING COOKING TIME





This function can be used to cook food for a set length of time, from a minimum of 1 minute to the maximum time allowed by the selected function, after which the oven switches off automatically.

1. To select the function, position the cursor next to "COOK TIME" using buttons .
2. Press button to select the setting; "00:00" flashes on the display.
3. Change the value using buttons and to display the desired cooking time.
4. Confirm the selected value by pressing button .

## BROWNING


At the end of cooking, with certain functions, the display indicates the possibility of browning the surface of your dish. This function can only be used when cooking time has been set.











At the end of cooking time, the display shows “^ to prolong, ✓ to brown”. Press button , and the oven starts a 5 minute browning cycle. This function can only be used once after cooking.

## SETTING END OF COOKING TIME / DELAYED START

The end of cooking time can be set, delaying the start of cooking by up to a maximum of 23 hours and 59 minutes. This can only be done once cooking time has been set. **This setting is only possible when pre-heating is not required for the selected function.**



After setting cooking time, the display shows the end of cooking time (for example 19:20). To delay the end of cooking time, and thus also the cooking start time, proceed as follows:

1. Position the cursor next to the end of cooking time using buttons  .
2. Press button  to select the setting: the end of cooking time flashes.
3. To delay the end of cooking time, use buttons  and  to set the desired value.
4. Confirm the selected value by pressing button .
5. Press button . The display indicates which shelf food should be placed on.
6. Press button  to activate the function. The oven will start cooking after a period of time calculated so as to finish cooking at the set time (for example, in the case of a dish which requires a cooking time of 20 minutes, if the end of cooking time is set to 20.10, the oven will begin cooking at 19.50).

**N.B:** during the interval before cooking starts, the oven can in any case be switched on by pressing button .


At any time during cooking, set values (temperature, grill setting, cooking time) can be changed using buttons   and button  as described in previous paragraphs.

## INDICATION OF THE RESIDUAL HEAT INSIDE THE OVEN








If at the end of cooking, or when the oven is switched off, the temperature inside the oven is over 50°C, the display shows the current temperature and the bar indicating cooling in progress. When the residual heat reaches 50°C, the display shows the current time.

## TIMER




This function can be used only with the oven switched off and is useful, for example, for monitoring the cooking time of pasta. The maximum time which can be set is 1 hour 30 minutes.


1. With the oven switched off, press button : the display will show “00:00:00”.
2. Press buttons  and  to select the desired time.
3. Press button  to start the countdown. When the set time has elapsed, the display will show “00:00:00” and an acoustic signal will sound. At this point the time can be prolonged, proceeding as described above, or the timer can be deactivated by pressing button  (the time of day will be shown on the display).

## RECIPES

Thanks to “Sixth sense” technology, the oven offers 30 pre-set recipes with ideal cooking temperatures. Simply follow the recipe as regards ingredients and the method of preparation. Then, proceed as follows:



1. Select “RECIPES” using buttons and confirm with .
2. Select the dish to be cooked from the proposed list.
3. Confirm the selected dish using button .
4. Select the desired recipe using buttons .
5. Confirm by pressing button : the display shows the approximate cooking time.
6. Put the food in the oven and press button . The display indicates which shelf food should be placed on.
7. Press button to start cooking. To delay the start of cooking, see the relevant paragraph.




**NOTES: some dishes must be turned or stirred half way through cooking: the oven will emit an acoustic signal and the display will indicate what action is required.**

**The initial cooking time displayed is merely for guidance: it can be prolonged automatically during cooking.**

Shortly before cooking time finishes, the oven prompts you to check that the food is cooked to your satisfaction. If it is not, extra time can then be added manually using the buttons .

## SHORTCUTS



1. Press button : the display shows the 10 most used functions.
2. To scroll down the list, use buttons .
3. Press to select the desired function.
4. To change the settings of the selected function, proceed as shown in the previous paragraphs.

## SETTINGS

1. To change some display settings, select “SETTINGS” from the main menu using buttons .
2. Confirm by pressing : the display shows which settings can be changed (language, volume of acoustic signal, display brightness, time, energy saving function).
3. Select the setting you wish to change using buttons .
4. Press button to confirm.
5. Follow the instructions of the display to change the settings.
6. Press : a message appears on the display confirming your selection.

**N.B:** when the oven is switched off, if the ECOMODE (energy saving) function is selected (ON), the display switches off after a few seconds. If, on the other hand, the function is not selected (OFF), after a few seconds the display is merely dimmed.











## KEY-LOCK







This function can be used to lock the control panel buttons.

To activate it, press and at the same time for at least 3 seconds. If activated, the functions of the buttons are locked and the display shows a message and the symbol . This function can also be activated during cooking. To deactivate it, repeat the above procedure. When the key-lock function is activated, the oven can be switched off using button .






















## FUNCTION DESCRIPTION TABLE

### MAIN MENU


















|  |                        |  |
|--|------------------------|--|
|    | <b>SETTINGS</b>        | Setting the display (language, time, brightness, volume of acoustic signal, energy saving function).   |
|    | <b>RECIPES</b>         | Selecting 30 different pre-set recipes (see enclosed recipe booklet). The oven automatically sets the optimum cooking temperature, function and time. It is important to follow the instructions given in the recipe book regarding preparation, accessories and which oven shelf to use.  |
|    | <b>TRADITIONAL</b>     | See TRADITIONAL FUNCTIONS.   |
|    | <b>SPECIALS</b>        | See SPECIAL FUNCTIONS.   |
| <b>TRADITIONAL FUNCTIONS</b>   |                        |  |
|    | <b>FAST PREHEATING</b> | To preheat the oven rapidly.   |
|    | <b>CONVENTIONAL</b>    | To cook any kind of dish on one shelf only. Use the 3rd shelf. To cook pizza, savoury pies and sweets with liquid fillings, use the 1st or 2nd shelf. The oven does not have to be preheated.  |
|   | <b>GRILL</b>           | To grill steak, kebabs and sausages; to cook vegetables au gratin and toast bread. Place food on the 4th or 5th shelf. When grilling meat, use the drip tray to collect the cooking juices. Position it on the 3rd/4th shelf, adding approx. half a litre of water. The oven does not have to be preheated. During cooking the oven door must remain closed.   |
|  | <b>TURBO GRILL</b>     | To roast large joints of meat (legs, roast beef, chickens). Position the food on the middle shelves. Use the drip tray to collect the cooking juices. Position it on the 1st/2nd shelf, adding approx. half a litre of water. The oven does not have to be preheated. During cooking the oven door must remain closed. With this function you can also use the turnspit, if provided.  |
|  | <b>FORCED AIR</b>      | To cook a variety of food requiring the same cooking temperature on several shelves (maximum three) at the same time (e.g.: fish, vegetables, cakes). This function can be used to cook different foods without odours being transferred from one food to another. Use the 3rd shelf to cook on one shelf only, the 1st and 4th to cook on two shelves, and the 1st, 3rd and 5th to cook on three shelves. The oven does not have to be preheated. |
|  | <b>CONVECTION BAKE</b> | To cook meat and pies with liquid filling (savoury or sweet) on a single shelf. Use the 3rd shelf. The oven does not have to be preheated.   |




| SPECIAL   |                     |   |
|---|---------------------|---|
|  | <b>DEFROSTING</b>   | To speed up defrosting of food. Place food on the middle shelf. Leave food in its packaging in order to prevent it from drying out on the outside.  |
|  | <b>KEEP WARM</b>    | For keeping just-cooked food hot and crisp (e.g: meat, fried food or flans). Place food on the middle shelf. The function will not activate if the temperature in the oven is above 65°C.   |
|  | <b>RISING</b>       | For optimal rising of sweet or savoury dough. To safeguard the quality of proving, the function will not activate if the temperature in the oven is above 50°C. Place the dough on the 2nd shelf. The oven does not have to be preheated.   |
|  | <b>CONVENIENCE</b>  | Cooking ready meals kept at room temperature or from refrigerated cabinets (biscuits, liquid cake mixtures, muffins, first courses and bakery products). This function gently cooks all food quickly; it can also be used to reheat cooked food. Follow the instructions on the food packaging. The oven does not have to be preheated. |
|  | <b>MAXI COOKING</b> | To cook large joints of meat (above 2.5 kg). Use the 1st or 2nd shelves, depending on the size of the joint. The oven does not have to be preheated.  |
|  | <b>FROZEN FOOD</b>  | <b>Lasagne</b>  |
|   |                     | <b>Pizza</b>  |
|   |                     | <b>Strudel</b>  |
|   |                     | <b>French fries</b>   |
|   |                     | <b>Bread</b>  |
|   |                     | <b>Custom</b>   |
|   |                     | The function automatically selects the ideal cooking temperature and mode for 5 different types of ready frozen food. Use the 2nd or 3rd shelf. The oven does not have to be preheated.   |
|   |                     | The temperature can be set from 50 to 250°C to cook other types of product.   |

## COOKING TABLES
















| Recipe  | Function  | Pre-heating | Shelf (from bottom) | Temperature (°C) | Time (min) | Accessories  |
|---|---|-------------|---------------------|------------------|------------|--|
| Leavened cakes                                |    | -           | 2 / 3               | 160-180          | 30-90      | Cake tin on wire shelf   |
|   |    | -           | 1-4                 | 160-180          | 30-90      | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf   |
| Filled pies (cheesecake, strudel, apple pie)  |    | -           | 3                   | 160-200          | 35-90      | Drip tray/ baking tray or cake tin on wire shelf   |
|   |    | -           | 1-4                 | 160-200          | 40-90      | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf   |
| Biscuits/Tartlets                             |    | -           | 3                   | 170-180          | 20-45      | Drip tray or baking tray   |
|   |    | -           | 1-4                 | 160-170          | 20-45      | Shelf 4: wire shelf<br>Shelf 1: drip tray or baking tray   |
|   |    | -           | 1-3-5               | 160-170          | 20-45      | Shelf 5: oven tray on wire shelf<br>Shelf 3: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray          |
|   |    | -           | 3                   | 180-200          | 30-40      | Drip tray or baking tray   |
|   |    | -           | 1-4                 | 180-190          | 35-45      | Shelf 4: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray  |
| Choux pastry                                  |   | -           | 1-3-5               | 180-190          | 35-45      | Shelf 5: oven tray on wire shelf<br>Shelf 3: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray          |
|   |  | -           | 3                   | 90               | 110-150    | Drip tray or baking tray   |
|   |  | -           | 1-4                 | 90               | 140-160    | Shelf 4: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray  |
|   |  | -           | 1-3-5               | 90               | 140-160    | Shelf 5: oven tray on wire shelf<br>Shelf 3: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray          |
|   |  | -           | 1 / 2               | 190-250          | 20-50      | Drip tray or baking tray   |
| Bread / Pizza / Focaccia                      |  | -           | 1-4                 | 190-250          | 25-50      | Shelf 4: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray  |
|   |  | -           | 1-3-5               | 190-250          | 25-50      | Shelf 5: oven tray on wire shelf<br>Shelf 3: oven tray on wire shelf<br>Shelf 1: drip tray or baking tray          |
|   |  | -           | 3                   | 180-190          | 40-55      | Cake tin on wire shelf   |
|   |  | -           | 1-4                 | 180-190          | 45-60      | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf   |
|   |  | -           | 1-3-5               | 180-190          | 45-60      | Shelf 5: cake tin on wire shelf<br>Shelf 3: cake tin on wire shelf<br>Shelf 1: drip tray or baking tray + cake tin |
| Savoury pies (vegetable pie, quiche lorraine) |  | -           | 3                   | 180-190          | 40-55      | Cake tin on wire shelf   |
|   |  | -           | 1-4                 | 180-190          | 45-60      | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf   |
|   |  | -           | 1-3-5               | 180-190          | 45-60      | Shelf 5: cake tin on wire shelf<br>Shelf 3: cake tin on wire shelf<br>Shelf 1: drip tray or baking tray + cake tin |
|   |  | -           | 3                   | 180-190          | 40-55      | Cake tin on wire shelf   |
|   |  | -           | 1-4                 | 180-190          | 45-60      | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf   |




| Recipe  | Function  | Pre-heating | Shelf (from bottom) | Temperature (°C) | Time (min) | Accessories   |
|---|---|-------------|---------------------|------------------|------------|---|
| Vols-au-vent / Puff pastry crackers                   |    | -           | 3                   | 190-200          | 20-30      | Drip tray or baking tray  |
|   |    | -           | 1-4                 | 180-190          | 20-40      | Shelf 4: oven tray on wire shelf  |
|   |   |             |                     |                  |            | Shelf 1: drip tray or baking tray   |
|   |   | -           | 1-3-5               | 180-190          | 20-40      | Shelf 5: oven tray on wire shelf  |
|   |   |             |                     |                  |            | Shelf 3: oven tray on wire shelf  |
|   |   |             |                     |                  |            | Shelf 1: drip tray or baking tray   |
| Lasagna / Baked pasta / Cannelloni / Flans            |    | -           | 3                   | 190-200          | 45-55      | Oven tray on wire shelf   |
| Lamb / Veal / Beef / Pork 1 Kg                        |    | -           | 3                   | 190-200          | 80-110     | Drip tray or oven tray on wire shelf  |
| Chicken / Rabbit / Duck 1 Kg                          |    | -           | 3                   | 200-230          | 50-100     | Drip tray or oven tray on wire shelf  |
| Turkey / Goose 3 Kg                                   |    | -           | 2                   | 190-200          | 80-130     | Drip tray or oven tray on wire shelf  |
| Baked fish / en papillote (fillet, whole)             |    | -           | 3                   | 180-200          | 40-60      | Drip tray or oven tray on wire shelf  |
| Stuffed vegetables (tomatoes, courgettes, aubergines) |    | -           | 2                   | 180-200          | 50-60      | Oven tray on wire shelf   |
| Toast   |  | -           | 5                   | High             | 3-5        | Grill   |
| Fish fillets / steaks                                 |  | -           | 3-4                 | Medium           | 20-30      | Shelf 4: wire shelf (turn food halfway through cooking)   |
|   |   |             |                     |                  |            | Shelf 3: drip tray with water   |
| Sausages / Kebabs / Spare ribs / Hamburgers           |  | -           | 4-5                 | Medium - High    | 15-30      | Shelf 5: wire tray (turn food halfway through cooking)  |
|   |   |             |                     |                  |            | Shelf 4: drip tray with water   |
| Roast chicken 1-1.3 Kg                                |  | -           | 1-2                 | Medium           | 55-70      | Shelf 2: wire tray (turn food two thirds of the way through cooking)                                |
|   |   |             |                     |                  |            | Shelf 1: drip tray with water   |
|   |   | -           | 1-2                 | High             | 60-80      | Shelf 2: Rotisserie   |
|   |   |             |                     |                  |            | Shelf 1: drip tray with water   |
| Roast Beef rare 1 Kg                                  |  | -           | 3                   | Medium           | 35-45      | Oven tray on wire shelf (turn food two thirds of the way through cooking if necessary)              |
| Leg of lamb / Shanks                                  |  | -           | 3                   | Medium           | 60-90      | Drip tray or oven tray on wire shelf (turn food two thirds of the way through cooking if necessary) |
| Roast potatoes  |  | -           | 3                   | Medium           | 45-55      | Drip tray or baking tray (turn food two thirds of the way through cooking if necessary)             |
| Vegetables au gratin                                  |  | -           | 3                   | High             | 10-15      | Oven tray on wire shelf   |
| Lasagna & Meat  |  | -           | 1-4                 | 200              | 50-100     | Shelf 4: oven tray on wire shelf  |
|   |   |             |                     |                  |            | Shelf 1: drip tray or oven tray on wire shelf   |

| Recipe            | Function  | Pre-heating | Shelf (from bottom) | Temperature (°C) | Time (min) | Accessories                                   |
|-------------------|---|-------------|---------------------|------------------|------------|---|
| Meat & Potatoes   |  | -           | 1-4                 | 200              | 45-100     | Shelf 4: oven tray on wire shelf              |
|                   |   |             |                     |                  |            | Shelf 1: drip tray or oven tray on wire shelf |
| Fish & Vegetables |  | -           | 1-4                 | 180              | 30-50      | Shelf 4: oven tray on wire shelf              |
|                   |   |             |                     |                  |            | Shelf 1: drip tray or oven tray on wire shelf |
| Frozen pizza      |  | -           | 3                   | Auto             | 10-15      | Drip tray / baking tray or wire shelf         |
|                   |   | -           | 1-4                 | Auto             | 15-20      | Shelf 4: oven tray on wire shelf              |
|                   |   |             |                     |                  |            | Shelf 1: drip tray or baking tray             |
|                   |   | -           | 1-3-5               | Auto             | 20-30      | Shelf 5: oven tray on wire shelf              |
|                   |   |             |                     |                  |            | Shelf 3: drip tray or baking tray             |
|                   |   |             |                     |                  |            | Shelf 1: oven tray on wire shelf              |
|                   |   | -           | 1-3-4-5             | Auto             | 20-30      | Shelf 5: oven tray on wire shelf              |
|                   |   |             |                     |                  |            | Shelf 4: drip tray or baking tray             |
|                   |   |             |                     |                  |            | Shelf 3: drip tray or baking tray             |
|                   |   |             |                     |                  |            | Shelf 1: oven tray on wire shelf              |

**Table of Tested Recipes (in compliance with IEC 60350:99+A1:05 +A2:08 and DIN 3360-12:07:07)**

| Recipe                            | Function  | Preheating | Shelf<br>(from the bottom) | Temperature<br>(°C) | Time<br>(min) | Accessories and Notes   |
|-----------------------------------|---|------------|----------------------------|---------------------|---------------|---|
| IEC 60350:99+A1:05 +A2:08 § 8.4.1 |   |            |                            |                     |               |   |
| Shortbread                        |    | -          | 3                          | 170                 | 20-30         | Drip tray / baking tray   |
|                                   |    | -          | 1-4                        | 160                 | 20-30         | Shelf 4: baking tray<br>Shelf 1: drip tray  |
| IEC 60350:99+A1:05 +A2:08 § 8.4.2 |   |            |                            |                     |               |   |
| Small cakes                       |    | -          | 3                          | 170                 | 25-35         | Drip tray / baking tray   |
|                                   |    | -          | 1-4                        | 160                 | 30-40         | Shelf 4: baking tray<br>Shelf 1: drip tray  |
|                                   |   |            |                            |                     |               |   |
|                                   |    | -          | 1-3-5                      | 160                 | 35-45         | Shelf 5: oven tray on wire shelf<br>Shelf 3: baking tray<br>Shelf 1: drip tray          |
|                                   |   |            |                            |                     |               |   |
| IEC 60350:99+A1:05 +A2:08 § 8.5.1 |   |            |                            |                     |               |   |
| Fatless sponge cake               |    | -          | 2                          | 170                 | 30-40         | Cake tin on wire shelf  |
| IEC 60350:99+A1:05 +A2:08 § 8.5.2 |   |            |                            |                     |               |   |
| Two apple pies                    |    | -          | 2 / 3                      | 185                 | 70-90         | Cake tin on wire shelf  |
|                                   |    | -          | 1-4                        | 175                 | 75-95         | Shelf 4: cake tin on wire shelf<br>Shelf 1: cake tin on wire shelf                      |
| IEC 60350:99+A1:05 +A2:08 § 9.1.1 |   |            |                            |                     |               |   |
| Toast                             |  | -          | 5                          | High                | 3-5           | Grill   |
| IEC 60350:99+A1:05 +A2:08 § 9.2.1 |   |            |                            |                     |               |   |
| Burgers                           |  | -          | 5                          | High                | 20-30         | Shelf 5: wire tray (turn food halfway through cooking)<br>Shelf 4: drip tray with water |
|                                   |   |            |                            |                     |               |   |
| DIN 3360-12:07 § 6.5.2.3          |   |            |                            |                     |               |   |
| Apple cake, yeast tray cake       |  | -          | 3                          | 180                 | 35-45         | Drip tray / baking tray   |
|                                   |  | -          | 1-4                        | 160                 | 55-65         | Shelf 4: baking tray<br>Shelf 1: drip tray  |
| DIN 3360-12:07 § 6.6              |   |            |                            |                     |               |   |
| Roast pork                        |  | -          | 3                          | 190                 | 150-170       | Shelf 3: grill<br>Shelf 2: drip tray with water (top up when necessary)                 |
|                                   |   |            |                            |                     |               |   |
| DIN 3360-12:07 annex C            |   |            |                            |                     |               |   |
| Flat cake                         |  | -          | 3                          | 170                 | 40-50         | Drip tray / baking tray   |
|                                   |  | -          | 1-4                        | 170                 | 45-55         | Shelf 4: baking tray<br>Shelf 1: drip tray  |

The cooking table advises the ideal function and cooking temperature to ensure the best results with all recipes. If you wish to cook on one shelf only using the fan-assisted function, place food on the third shelf and select the temperature recommended for the "FORCED AIR"  function when cooking on more than one shelf.

When grilling food, leave a space of 3-4 cm at the front to facilitate removal from the oven.

## RECOMMENDED USE AND TIPS

### How to read the cooking table

The table indicates the best function to use for any given food, to be cooked on one or more shelves at the same time. Cooking times start from the moment food is placed in the oven, excluding pre-heating (where required). Cooking temperatures and times are purely for guidance and will depend on the amount of food and type of accessory used. Use the lowest recommended values to begin with and, if the food is not cooked enough, then move on to higher values. Use the accessories supplied and preferably dark coloured metal cake tins and oven trays. You can also use pans and accessories in pyrex or stoneware, but bear in mind that cooking times will be slightly longer. To obtain best results, carefully follow the advice given in the cooking table for the choice of accessories (supplied) to be placed on the various shelves.

### Cooking different foods at the same time

Using the "CONVECTION BAKE" function, you can cook different foods which require the same cooking temperature at the same time (for example: fish and vegetables), using different shelves. Remove the food which requires less cooking time and leave food which requires longer cooking time in the oven.

### Desserts

- Cook delicate desserts with the conventional function on one shelf only. Use dark coloured metal cake tins and always position them on the wire shelf supplied. To cook on more than one shelf, select the forced air function and stagger the position of the cake tins on the shelves, aiding optimum circulation of the hot air.
- To check whether a raising cake is cooked, insert a wooden toothpick into the centre of the cake. If the toothpick comes out clean, the cake is ready.
- If using non-stick cake tins, do not butter the edges as the cake may not rise evenly around the edges.
- If the cake "sinks" during cooking, set a lower temperature the next time, perhaps reducing the amount of liquid in the mixture and mixing more gently.
- For sweets with moist fillings (cheesecake or fruit pies) use the "CONVECTION BAKE" function. If the base of the cake is soggy, lower the shelf and sprinkle the bottom of the cake with breadcrumbs or biscuit crumbs before adding the filling.

### Meat

- Use any kind of oven tray or pyrex dish suited to the size of the piece of meat being cooked. For roast joints, it is best to add some stock to the bottom of the pan, basting the meat during cooking for added flavour. When the roast is ready, let it rest in the oven for another 10-15 minutes, or wrap it in aluminium foil.
- When you want to grill meat, choose cuts with an even thickness all over in order to achieve uniform cooking results. Very thick pieces of meat require longer cooking times. To prevent the meat from burning on the outside, lower the position of the wire shelf, keeping the food farther away from the grill. Turn the meat two thirds of the way through cooking.

To collect the cooking juices it is advisable to place a drip-tray with half a litre of water directly under the grill on which the meat is placed. Top-up when necessary.

### Turnspit (only in some models)

Use this accessory to evenly roast large pieces of meat and poultry. Place the meat on the spit rod, tying it with string if chicken, and check that it is secure before inserting the rod in the seat located on the front wall of the oven and resting it on the respective support. To prevent smoke and to collect cooking juices, it is advisable to place a drip-tray with half a litre of water on the first level. The rod has a plastic handle which must be removed before starting to cook, and used at the end of cooking to avoid burns when taking the food out of the oven.

### Pizza

Lightly grease the trays to ensure the pizza has a crispy base. Scatter the mozzarella over the pizza two thirds of the way through cooking.

### Dough proving function

It is always best to cover the dough with a damp cloth before placing it in the oven. Dough proving time with this function is reduced by approximately one third compared to proving at room temperature (20-25°C). Proving time for a 1 Kg batch of pizza dough is around one hour.